Molok[®] Deep Collection[™] containers without quick system

Please read through the instructions before emptying. Always use caution and be careful when lifting. Inspect the condition of the lifting loops and the lifting bag before lifting. Pay attention to occupational safety; do not suspend the load above people or objects and keep a safe distance from the load. Please note that the bags may contain items that do not belong in them. Also note that the lifting bag must not be moved with the help of the closing rope at any point during emptying. If the emptying truck is equipped with a hydraulic rotating hook, the rotation must not be activated before the container has been completely lifted out of the well body.

Attach the lifting strap to the loops on the bag.

Open the lock/hatch and remove the lid, or open the hinged lid. Always use the four-branch lifting strap to lift the bag. The maximum angle of the strap is 60 degrees; select the correct strap type and observe the safe working load limits. Each lifting strap section must be at least 1.2 metres long. Each strap section must be of equal length. If the lifting strap is too short, it causes an additional load both on the lifting bag and the hoop. Always attach the hooks to the lifting bag, each to its own designated lifting hoop. Depending on the size of the container, there are three or four lifting loops. Never lift a lifting bag if all of its lifting points are not in use. After attaching the hooks to the lifting loops, step away from the container.

Lifting the bag

Do not overload the lifting bag. Make sure that the safe working load (=SWL) is not exceeded. SWL is marked on the product certificate on the side of the bag, and it is visible during stage 1 of lifting.

Lift the bag in two stages

- 1. Lift the bag a little bit to reveal the release rope. Move closer to the container to detach the rope from the loop. You can also check the SWL number at this point. After this, step away from the container. Start lifting slowly and steadily in order to balance out the underpressure in the container. Be particularly careful during emptying if the container is overfull or if you notice that the bag contains items that do not belong in it. Stop lifting if needed.
- 2. Lift the bag fully from the container and move it above the emptying truck with the crane. Note! Keep the bag straight during lifting. The bag must be completely outside of the body before being moved to the side. Keep a safe distance from the lifting bag. Do not go under the load.

The bottom of the bag is opened as illustrated in the rope lock, by pulling diagonally on the safety lock to remove the rope from the locking device. After this, pull the rope out of the loop to open the bottom. After emptying, close the bag tightly by pulling on the rope. Place the rope guide in the loop of the rope lock and insert the rope in the locking device, following the instructions on the bag. Next, use the crane to move the bag above the container and lower it towards the container so that you can coil and attach the release rope to the attachment loops.

Finally, lower the lifting bag into place. Make sure that the bag is straight in its own place. Ensure that each supporting rod is on top of the container edges. Close the lid and the hatch or lock. Check that the filling lid is in the right place on top of the container so that the opening is in line with the waste type label. Do not insert your fingers between the container and the lid or the opening.

Inspect the bag visually during emptying. Any broken or damaged parts must be immediately reported to the container owner. Small cuts or holes in the bag are allowed.

NOTE! There are short emptying instructions and illustrated locking instructions on the side of the lifting bag.



MOLOK

Lifting stage 1

