

## Molok® Domino BioSystem 1/6 (500 l)

Please read through the instructions before emptying. Always use caution and be careful when lifting. Inspect the condition of the inner container before lifting. Pay attention to occupational safety; do not suspend the load above people or objects and keep a safe distance from the load. Prevent liquid from spilling onto the ground during emptying. Please note that the containers may contain items that do not belong in them. Also note that the containers must not be moved with the help of the closing rope at any point during emptying. If the emptying truck is equipped with a hydraulic rotating hook, the rotation must not be activated before the container has been completely lifted out of the concrete body.

- Open the lid of the container to the side with the help of the side hinge. The triangular lock on the lid must be opened before opening the lid. If the lid is equipped with a quick equipment top bar, move the lid and the quick system to the side during emptying.
- Remove the cone that keeps the disposable bag in place during emptying. Newer container models have a rubber rope in place of the cone. Remove the rubber rope during emptying.
- If the container has four lifting points, use a four-branch lifting strap to lift the BioSystem inner container. Each of the four lifting strap sections must be at least 1.2 metres long. If the lifting strap is too short, it may damage the inner container. Always attach all four hooks to the lifting container, each to its own loop. Never lift a lifting bag if all of its four lifting points are not in use.
- If the container is equipped with a lifting handle, attach the lifting strap to the centre of the handle. Make sure that the attachment points of the lifting handle are in working order.
- Start lifting slowly and steadily. If you lift too fast, the inner container may become damaged. Keep the BioSystem inner container straight during lifting. If the container is lifted at an angle, the locking device, inner container and concrete body may be damaged. Ensure that the inner container does not hit the sides of the emptying truck. Do not overload the inner container. Make sure that the safe working load (=SWL) is not exceeded. The SWL is marked on the side of the inner container. Please note that the inner container must be completely outside of the body before being moved to the side.
- Lift the inner container out of the concrete body and open the safety pin. Lift the inner container above the emptying truck and open the locking device by pulling on the rope to open the bottom of the container. Pay attention to occupational safety, never go under the suspended load while the container is in the air.
- After emptying, place the inner container steadily on an even surface and fasten the locking device and the safety pin. Attach the rope to the designated spot. Inspect the container visually and make sure that all lifting loops or the lifting handle are undamaged and that the container attachment parts, the concrete body and metal parts are in working order. Any broken or damaged parts must be immediately reported to the container owner. Keep the inner container in a vertical position while you lower it back into place. Lower the container into the concrete body in a controlled manner. Do not drop the container! If the inner container is new, remember to place the inner container inside the concrete body so that the taller side is towards the centre. Turn the lifting handle down so that the lid is able to close. Avoid hitting the inner container or the concrete body while you lower the container. Make sure that the lid is in its right place, covering all sides of the container evenly.
- Installing a disposable bag with the help of the cone:
  - Place the disposable bag in the BioSystem container and attach the cone inside the bag. Turn the edges of the disposable bag inside of the cone.
- Installing a disposable bag with the help of an elastic band:
  - Place the disposable bag in the BioSystem container and fold the edges of the bag to the outside of the inner container. Place the elastic band around the disposable bag and the inner container to secure the bag in its place.
- Install the lid into place and fasten the lock.



Locking device:

1. Remove the safety pin.
2. Pull on the rope to open the bottom cup.